DIRECTIONS FOR CUTTING A SMALLER SMARTBAFFLE

SECOND CUT DETAIL

Corrugated plastic sheet

Utility knife

Figure A

This is for the Second Cut where only half the thickness is being cut.

Do not cut through the lower layer of the corrugated sheet. (This will allow for bending)

Rafter Space Plus 4"

1st Cut

Cut Here First at 4" wider than Rafter space. Cut completely through plastic.

2"

Rafter Space

2nd Cut

Second Cut (half way through plastic)

2"

Cut the Baffle 4" wider than the rafter space it is fitting into as shown above.

This cut is only half way through at 2" in from cut edge. See Figure A above

Discard this portion

CUT EDGE

Score the plastic half way deep at a 2" line in from the cut edge.

Directions: 1st Cut is 4" wider than rafter space. 2nd Cut is 2" in from cut edge and only cut half way through plastic sheet. Bend both flaps up towards roof deck and insert into rafter space. Proceed to insulate.

2" in from cut edge

Manufactured by DCI Products